





Conserv-a-trieve


GENERAL SPECIFICATIONS

1. An automatic electronic sequential, bulk storage and retrieval system. Especially conceived and designed to provide the greatest S.U.E. (Space Utilization Efficiency) available anywhere in bulk record storage and reduce labor requirements at an economical cost.
2. This system permits the automatic retrieval and storage of bulk containers of documents or material of varying description and size arranged in double banks as **high** and **as long** as the physical dimensions of the assigned area permits.
3. An operator at a "Sit-down" position would be able to demand by push-button a particular tub or cradle of filed material of a specific series. This would be conveyed to her at a speed of about 50 inches/second at desk height, to perform a pull or refile operation. The touch of a restore button would return the tub rapidly to the address retrieved from making the system ready for the next operation.
4. Search made electro-optically of a coded shelf opening. The tub of material stored in that opening is determined by cross reference, electronically or manually. Thus removal or condensing of material does not require any recoding only a change in the cross reference.
5. Conserv-a-trieve utilizes high reliability solid state components on plug-in glass epoxy, gold plated printed circuit boards for minimum maintenance and maximum reliability.
6. No change in document system or form is required in the utilization of this equipment. It can use folders or be folderless; terminal digit or sequential, etc.
7. The keyboard input consists of either:
 - a. A vertical and horizontal row of buttons representing X and Y of the storage matrix. At the intersection of lines drawn from each button will be a label identifying the tub contents. When the X and Y buttons are depressed the label at their intersection will light up verifying your request.
 - b. Or for extra long installations a 10 key input would be used in conjunction with a cross reference index.



CONSERVATION TRIEVE






ESTEY[®] E^NECOMPACT

YOUNG AND WATSON
3703 BONITA ST., S. E.
WASHINGTON, D. C. 20023
TEL. 423 - 1121




positions of continuity with each other, in a space which provides virtually a 100% use of floor space available in most installations, this would mean more than doubling the number of volumes shelved in a given space. Other advantages include: stepped up efficiency to the air conditioning function because of the reduction of unused air volume in high density storage, shorter walking distance needed by staff and library users, reduced dust, sharply reduced electric lighting because only the aisle being used is lighted, a system which has already begun to change the entire concept of efficient library storage! The cost of the Estey-Elecompact system is easily justified and in fact overall savings of building and equipment costs can be realized.



Installation shown: American University — Washington, D. C.




EASE OF OPERATION

- 1 Push the button of the aisle you want to use.
- 2 The aisle is lighted and opens automatically.
- 3 When finished, push the turn-off button at the entrance to the aisle. The system is again ready to be activated.



SAFETY OF OPERATION

- 1 Even if another button is pressed, when one aisle is lighted, the system will not operate.
- 2 In the event an object is left in an unlighted aisle, and someone else pushes the operation button, safety-bars at hip-height and toe-level would trigger the unit back to its former position.
- 3 (View from Above)
The safety-bars are continuous strips the entire length of the aisle at hip-height and toe-level. When they touch any person or object, that aisle is automatically opened up to its open position.



25X1A

T NSMITTAL SLIP		DATE 11 August 1959
TO: [REDACTED] C/Bldg. & Planning		
ROOM NO. 1012 Ames	BUILDING Staff	
REMARKS:		
<p>Attached are a few samples of current Floor space savings file equip- ment.</p> <p>There are many more types of this equipment. Please call on us if we can help.</p>		
FROM: [REDACTED]		
ROOM NO. 702	BUILDING Magazine	EXTENSION 3303
RM NO. 241 EB 55		

25X1A

25X1A

REPLACES FORM 36-8
WHICH MAY BE USED.

(47)